

BONA NATURALE 1-COMPONENT Sitework



Bona Naturale - the next generation of wooden floor protection from Bona. With the look and feel of pure wood.

Needed for application

1. Bona roller for a superior surface
2. Brush, edge roller or paint pad/cut-in pad for the edges
3. Bona Scrad system or screen 120-150

Preparing the surface for Bona Naturale

The surface which is to be treated must be well sanded, dry and free from sanding dust, oil, wax and other contamination. The Bona Scrad system, sanding disc/screen or abrasive grade no. 120-150 should be used for the final sanding of the wood. Best result is obtained using a buffing machine for the final sanding.

Application

Bona Naturale is a wood treatment system designed for use in a two coat application without the use of a primer. This treatment seals and deeply conditions the wood and will also form a superb wear layer.

- Shake the container thoroughly for at least 15 seconds prior to use.
- Apply evenly using a Bona roller, avoid accumulations of product to avoid discolorations. Do only use roller for Bona Naturale.
- Ensure that a "wet edge" is maintained during application to avoid "overlap" marks (treat an area of 3-5 m² at a time).

After the first application, raised grain should be removed by a light abrasion using a sanding screen grade no. 120 - 150 or the Bona Scrad system.

Application rate:

- Initial treatment: 7-9 m²/litre (140-110 g/m²).
- Second treatment: 8-10 m²/litre (120-100 g/m²).

Drying time:

- Initial treatment: 1,5 hour at 20°C/60% R.H.
- Second treatment: 2½-3 hours at 20°C/60% R.H.

Note: The temperature of the floor or Bona Naturale must not fall below +13°C during application and drying.

The floor can receive light foot traffic approximately 8 hours after the final application. The Bona Naturale treatment will be completely cured after approximately 1 week. The floor can then be cleaned using a damp cloth and Bona Parkett Cleaner or Bona Wood floor cleaner, and carpets/rugs can be laid.

Bona Naturale 1-component is a suitable choice for wooden floors including floors where there is a risk of sidebonding, e.g, softwood plank floors and hardwood floors with underfloor heating.

Maintenance and cleaning

- Frequent cleaning: use dry methods e.g. vacuum cleaning and dry mopping.
- Occasional cleaning to remove more difficult dirt: use Bona Parquet cleaner or Bona Wood floor cleaner.
- Spot repair damages and scratches: clean the area thoroughly. Sand the damaged area to remove dirt and even out sharp edges, apply one layer of Bona Naturale to the previously sanded area (i.e. only the damaged area), abrade, tape around the damaged board or wood block, apply a second layer of Bona Naturale to the whole wood board or block, remove the tape immediately.