



BONA PRIME DEEP

Sitework

Surface preparation

The surface which is to be treated must be even (i.e. not brushed or similar), well sanded, dry and free from sanding dust, oil, wax and other contamination. Prior to use it is recommended that all joints are filled with Bona Mix&Fill to avoid possible bleed back. The final sanding shall be done with a belt sander grit P120 followed by a sanding screen grit P150.

Precaution

Bona Prime Deep can be used on most wood species, however greasy and resin rich wood species such as ipé, wenge etc may have an adverse effect on the adhesion. If unsure, make an adhesion test.

Application

1. Shake the bottle well before use. Apply one coat of Bona Prime Deep evenly and thinly over the whole floor using a buffing machine (100-200 rpm). Put a Bona Oil cloth on the floor. Place a red pad - with the centre puck removed – over the cloth. Pour approx. 0,1 litre Bona Prime Deep into the centre of the pad. Add more Bona Prime Deep to the centre hole as required. Manually apply Bona Prime Deep to the edges using a Bona Oil cloth or a fine brush. Alternatively the whole application can be done using a stainless steel trowel. **Recommended coverage rate is 30-40 m²/litre.**
2. Within 15 minutes from the application, buff the floor using a new clean Bona Abrasive red pad followed by the removal of all remaining surplus material using a Bona Oil cloth wrapped around a clean pad under the buffing machine. **Note:** Failure to remove all surplus product will have an adverse effect on the adhesion.

WARNING: BONA PRIME DEEP CONTAINS DRYING OILS. RISK OF SELF-IGNITION. USED CLOTHS, RAGS AND SIMILAR SHOULD BE PLACED IN WATER OR SEALED METAL CONTAINERS.

3. Allow a minimum 12 but no more than 72 hours drying time. Ensure good ventilation and avoid foot traffic throughout the drying time. The temperature in the room must not fall below 18°C.
4. When the surface is fully dry, buff the floor using a Bona Oil Cloth wrapped around a clean pad. If glossy spots have appeared on the floor then prior to this operation remove the spots by buffing with a red pad.
5. Vacuum or wipe off the floor with a Bona microfiber mop or similar.
6. Apply one coat of **Bona Prime Intense**.
7. Apply 2 layers of a Bona waterborne topcoat of your choice.

Bona[®]