



General Description

Junckers BASEPRIME is a quick-drying primer which in combination with Junckers solvent-based or water-based lacquers is suitable for most sanded and untreated parquet floors, including most exotic wood floors.

Junckers BASEPRIME gives light-coloured woods a light-gold appearance.

Junckers BASEPRIME should only be used for priming.

Technical Data

Product:	Priming lacquer based on ethyl alcohol.
Package sizes:	10 litres
Appearance:	Colourless.
Coverage:	10 m ² per litre.
Application tools:	Brush or short-pile varnishing roller. Do not apply by spraying.
Substrate temperature:	Minimum 10°C.
Dilution:	Delivered ready for use. Dilution is not recommended.
Drying time:	Dry to touch approx. 15 min. at 20°C.
Cleaning of tools:	Junckers THINNER 007.
Storage:	Not to be exposed to temperatures below 0°C. Shelf life 2 year in unopened can stored at 20°C.

System Recommendations

High traffic areas:	1 coat Junckers BASEPRIME 10 m ² /ltr. + 2 coats Junckers High Performance Commercial 10m ² ltr.
or	
	1 coat Junckers BASEPRIME 10 m ² /ltr + 2-3 coats Junckers ISOLAK 10 m ² /ltr
or	
	1 coat Junckers BASEPRIME 10 m ² /ltr + 2 coats Junckers PROTECH 10 m ² /ltr
or	
	1 coat Junckers BASEPRIME 10 m ² /ltr + 2 coats Junckers STRONG 10 m ² /ltr
Low traffic areas:	1 coat Junckers BASEPRIME 10 m ² /ltr + 1-2 coats Junckers PROTECH 10 m ² /ltr
or	
	1 coat Junckers BASEPRIME 10 m ² /ltr + 1-2 coats Junckers PRO FINISH 10 m ² /ltr
Sport areas:	1 coat Junckers BASEPRIME 10 m ² /ltr. + 2 coats Junckers High Performance Sport 10m ² ltr
or	
	1 coat Junckers BASEPRIME 10 m ² /ltr + 2-3 coats Junckers ISOLAK 10 m ² /ltr

Directions for Use

Untreated/sanded floors

The surface should be clean, dry and free from dust, wax, grease, polish etc. Machine sand the floor as advised under **Previously lacquered floors** to remove dirt and irregularities. The last sanding should be carried out by using minimum grit 120-150 before applying **Junckers BASEPRIME**. Thoroughly clean off the sanding dust (e.g. by vacuuming).

Apply **Junckers BASEPRIME** in an even coat with a varnishing roller or brush. Let dry properly before sanding and application of the following coat of lacquer. The system is build up according to the System recommendations and the recommendations for each individual product in the system.

Previously lacquered floors:

Machine sand before applying Junckers PRELAK. Use grit 24 to strip old coats. Then remove abrasion marks with grit 60. Finally, use grit 120-150 to obtain a completely smooth surface. Vacuum sanding dust and prime the floor as described under "Untreated/ sanded floors".

Further technical information

Products:

- F 4.2 - Junckers PRO FINISH**
- F 5.1 - Junckers STRONG**
- F 6.2 - Junckers PROTECH**
- F 7.1 - Junckers ISOLAK**
- F 7.5 - Junckers THINNER 007**
- F 8.2 - Junckers High Performance Sport**
- F 8.5 - Junckers High Performance Commercial**

Important!

Before use of the product, read the label on the container carefully.