



General Description

Junckers RUSTIC OIL is impregnating oil for both priming and finishing of untreated internal wooden floors.

It can also be used for maintaining other oil treated surfaces.

Especially suited for treatment and maintenance of Junckers oiled Solid Hardwood floors and RUSTIC worktops.

Technical Data

Product:	Hardening urethane oil in paraffinic solvent.
Package sizes:	0.75 litre, 2.5 litres, 5 litres, 10 litres, and 25 litres.
Appearance:	Provides wood with a deep, warm glow.
Gloss:	The gloss level depends on the coverage of the final thin coats. Higher coverage gives a lower gloss level.
Coverage:	Oil-treated or impregnated wood: 20-50 m ² / litre. Untreated wood: 5-10 m ² per litre
Application tools:	Small areas (up to 4 m ²): Cloth, brush. Large areas (more than 4 m ²): Roller or spray in combination with a nylon scouring pad.
Substrate temperature:	Minimum 5°C.
Dilution:	Delivered ready for use. Dilution is not recommended.
Drying time:	Dry to touch after approx. 8 hours at room temperature. Ready to use after 24 hours.
Cleaning of tools:	White spirit or similar.
Storage:	Lasts for several years if unopened and stored at 20°C. Not to be exposed to temperatures above 40°C. Once open the oil will start to form a skin and harden in the can.

System Recommendations

- High traffic areas:** 1 impregnating coat RUSTIC OIL 5 m²/ltr +
2 thin coats RUSTIC OIL 50 m²/ltr.
High traffic areas should regularly be maintained. Apply a new thin coat of RUSTIC OIL to avoid the surface from turning dull.
- Low traffic areas:** 1 impregnating coat RUSTIC OIL 5 m²/ltr +
2 thin coats RUSTIC OIL 50 m²/ltr.
Maintain the surface by using RUSTIC OIL LIGHT. Use RUSTIC OIL when a tendency of dullness appears.

Directions for Use

Priming of untreated/sanded floors:

Ensure that the surface is absolutely clean, dry and free from dust, wax, grease, polish etc. Sand until surface is completely even using sandpaper, grit 120 or a similar soap free, clean abrasive nylon pad. Vacuum sanding dust and wipe the floor with a damp cloth and clean water.

Determine the level of wood absorption and impregnation by applying RUSTIC OIL to a small area first. The number of coats necessary depends on how much oil the floor will absorb. Softwood and beech absorb more than hard and exotic (oily) wood species. The oil should saturate the wood and not be allowed to dry on the surface.

Apply the oil and allow it to soak in for up to 30 minutes. If areas dry move the oil around or apply more. Do not allow the surface to dry. After maximum 30 minutes wipe off the excess oil. Dried and unabsorbed oil leaves glossy spots on the surface. The surface should be matt and even.

Plan your work well. Large areas should be divided into smaller areas 10-25 m². Leave the oil to dry 12-16 hours before the finishing treatment.

Finishing of primed wood:

Sand or scour the surface carefully with fine sandpaper grit 180 or a similar nylon pad. Apply RUSTIC OIL according to the level of absorption as described under "Priming of Untreated/sanded Floors". Remove surplus oil within 30 minutes with a dry soft cloth and buff the surface to an even finish using the cloth. Repeat the treatment after 6-8 hours.

The surface is ready for use 24 hours after application of the last coat.

Wait a few days before replacing rugs or carpets.

Important!

Never use steel wool for sanding as the wood can be discoloured when exposed to moisture later on.

Important!

Before use of the product, read the label on the container carefully.